

Installation Step Lift

Screw the **Step Lift** into the three pre-drilled holes on the Tech Lift 500 with M5x12 and the **Step Lift** is mounted.

