

TECH LIFT M4

Reset

To activate the reset, turn the knob clockwise (see picture 1) and hold for about 10 sec, the lift starts and goes slowly downwards lamp fault lights up (NOTE! with this downward movement, crushing protection is not activated, take extra care and make sure that no obstacles are found under the platform). Hold the knob down during the entire lift movement and release it only when the light fault (see picture 2) has gone out and the lift is at the bottom.



Picture 1



Picture 2

TECHLINE
SWEDEN AB

Tech Line Sweden AB

Kyrkbacken 2

SE-507 90 Brämhult

Email: info@techline.nu

Phone: +46 (0)723 735506 or +46 (0)709 837972

Webpage: www.techline.nu

VAT-nr: SE559248058501